

# Suma<sup>®</sup> Oven D9.6

## Oven Cleaner



---

**Premium, ready-to-use grill and oven cleaner.**

### Effective

- ▶ Use where large areas of medium to heavy soil are encountered
- ▶ Removes heavy deposits of grease, fats and carbonized soil
- ▶ Clings to vertical surfaces for longer contact time, better overall coverage

### Easy-to-Use

- ▶ Rinses quickly and completely to reduce overall cleaning time
- ▶ Easy to apply

---

### Designed For

- ▶ Health Care
  - ▶ Food Service
  - ▶ Lodging
  - ▶ Education
- 



# Use Overview

**Suma® Oven D9.6 Oven Cleaner** is a premium, ready-to-use grill and oven cleaner. Highly-alkaline detergent is suitable for cleaning of heavily soiled ovens and grills. This blend of alkali, surfactants and solvents removes even heavily carbonized soil.

- ▶ Always wear long rubber gloves and eye protection when spraying and wiping. Wash hands and arms after use. Do not spray on or let contact pilot light, electrical connections, switches, light bulbs, heating elements, receptacles, or thermostats. Spray may cause electric short. Do not let product contact floor coverings, linoleum, aluminum, copper, chrome, painted surfaces or plastics. Do not use on continuous or self-cleaning ovens.



## Grill Cleaning

- ▶ Pre-scrape surface to remove gross soils. Adjust grill temperature to 150 - 180°F (65.6 – 82.2°C).
- ▶ Dispense or mix proper strength solution of product in a bucket or spray bottle if diluting product.
- ▶ Spray or spread product onto grill surface and let stand for several minutes. Do not allow grill surface to dry. Reapply product if necessary.
- ▶ Wipe grill with a cloth. Repeat as necessary until grill is clean.
- ▶ Rinse thoroughly with water and wipe dry. If desired, season the grill by coating the surface lightly with cooking oil.

## Oven Cleaning

- ▶ Remove all racks from the oven. Clean racks in the three-compartment sink or dish machine.
- ▶ Dispense or mix proper strength solution of product in a bucket or spray bottle if diluting product.
- ▶ Spray or spread product onto the interior of the oven. Allow to stand for up to 30 minutes.
- ▶ Wipe oven with a cloth. Repeat as necessary until oven is clean.
- ▶ Rinse thoroughly with water and wipe dry. Replace oven racks.
- ▶ Start oven and allow oven to run for several minutes before next use.

**Storage:** Do not store in food processing or food storage areas.

## Product Specifications

Description	
<b>Certifications</b>	Kosher
<b>Color/Form</b>	Clear tan, liquid
<b>Flash Point</b>	>200° F (> 93.4° C)
<b>pH</b>	12.57 12.28 (Use Dilution 1:12)
<b>Scent</b>	Glycol Ether
<b>Shelf Life</b>	2 years
<b>Solubility</b>	Complete
<b>Specific Gravity</b>	1.074

## Available Items

Product Code	Description/Package Size	Dilution
57278280	4 x 1 gallon / 3.78 L Containers	Ready-To-Use-1:12

## Safety Reminder

Please make sure your employees read and understand the product label and Material Safety Data Sheet before using this product. The label contains directions for use, and both the label and MSDS contain hazard warnings, precautionary statements and first aid procedures. MSDS are available on-line at [www.diversey.com](http://www.diversey.com) or by calling 888 352 2249.

## Hazard Rating

HMIS		NFPA
3	Health	3
0	Flammability	0
0	Reactivity	0

4=Very High; 3=High; 2=Moderate; 1=Slight; 0=Insignificant.