



HELPLINE 1-800-282-2886

8 a.m. to 7:30 p.m. (CST), Monday - Friday 10 a.m. to 6:30 p.m. (CST), Saturday - Sunday

www.eureka.com



Vhat's in the carton

Dusting


Brush




Vacuum Base













Easy assembly






Slide vacuum back onto base. Fasten with one long screw.



Push end of base hose into opening on vacuum base.




Hose

Extension

Wand and


Slide tool caddy onto back. Fasten with two short screws.




Slide handle onto tool caddy. Fasten with one long screw.




Attach hose to vacuum back. Fasten with two short screws.




Attach hose retainer with one short screw. Pull retainer out to position hose.




Pull up cord and push into lower cord retainer.




Push cord into upper cord retainer. Place hose over hose hook on handle.




For models without a duster, connect hose into lower base hose.




Some models: Secure bottom of duster chamber to hose retainer. Tighten with flat-head screwdriver.




Push end of hose into duster chamber. Place duster in chamber and snap into place.




Place dust cup on base and snap into place.




Wrap cord. Place wand/crevice tool in holder on side of vacuum.



Place dusting brush on back of handle.




Some models: Snap Power Paw® into clip on front.




For accessories: Loosen lower end of hose from vacuum and attach tool.




Get ready to vacuum




Step on power switch to turn on; step on again to turn off.



Step on handle release to lower handle into position.



raise carpet setting.



Lift latch to remove dust cup. Empty after each use.