



# NAVIGATOR

## Dilution Control System

### Why It's A Better System

- Concentrate and RTU labels are numbered and color coded for safety and to facilitate training
- Closed system - Spill proof container
- New Metered Tip with each concentrate provides proper dilution each time
- English/Spanish label copy
- Each concentrate has an easy carry handle
- Recyclable container

### Why It's A Better Cleaner

- Broad spectrum efficacy - Kills a wide range of organisms including HIV-1, MRSA, HBV and HCV.
- Multi-purpose detergent - Cleans soils from many hard surfaces
- Quaternary based - Hospital use disinfectant
- Water based, nonalkaline formula - Can be used on inanimate washable surfaces

### How It Cleans



Dispense precisely diluted cleaner into a clean, empty container. If solution is for reuse, properly label NAVIGATOR RTU #9 Multi-Purpose Disinfectant container.



**CLEAN AND DISINFECT:**  
Remove gross soil mechanically before cleaning begins.



Apply solution with wiper, mop or sponge, making sure to wet all surfaces thoroughly.



Scrub. Discard solution when it becomes dirty and replace with fresh solution.



Allow surfaces to remain wet for 10 minutes. Remove excess liquid and let air dry.

### Navigator Dispensers

Low-Flow Dispenser . . . . . Product No. 13172  
 High-Flow Dispenser . . . . . Product No. 13173  
 Dispenser Connector Kit . . . . . Product No. 13182

# 9 MULTI-PURPOSE DISINFECTANT

EPA Registered Disinfectant

### Where It Cleans

- Floors, walls
- Mirrors, glass
- Metal surfaces
- Conductive flooring
- Painted surfaces
- Exterior bowl surfaces
- Empty basins
- Non-critical medical devices
- Hair/nail care instruments
- Showers, lavatory fixtures
- Tanning beds
- Other hard, Nonporous surfaces

### Technical Data

Packaging (concentrate) . . . . . 2/2 Liters per case  
 Product Number . . . . . 13160  
 Concentrate Color . . . . . Light Blue  
 RTU Color . . . . . Light Blue Tint  
 RTU Fragrance . . . . . Fresh Clean  
 Foaming . . . . . Low-Moderate  
 Free-Rinsing . . . . . Yes  
 % Phosphates . . . . . None  
 RTU pH . . . . . 7.0  
 EPA Registered . . . . . Yes  
 RTU Yield Low-Flow . . . . . 972 Quarts per case  
 RTU Yield High-Flow . . . . . 243 Gallons per case

### Efficacy

*Pseudomonas aeruginosa*,  
*Staphylococcus aureus*,  
*Salmonella choleraesuis*,  
*Escherichia coli*, *Staphylococcus aureus* (MRSA), *Staphylococcus aureus* (VISA), *Streptococcus pyogenes*, *Enterococcus faecalis* (VRE), Canine distemper, Feline leukemia, Hepatitis B (HBV), Hepatitis C (HCV), Herpes simplex type 1 & 2, HIV-1 (AIDS virus), Pseudorabies, SARS Associated Coronavirus, and many more.



NAVIGATOR 2-Liter bottles are designed to be used in the NAVIGATOR Dilution Control System.