

New Power Against Environmental Surface Contamination

Exclusive flip-top lid!



Here's an effective, easy-to-use and economical alternative to spray bottle or cloth and open bucket disinfecting/cleaning systems. The Sanotex system can help you reduce risk and simplify the process – saving time and money while bringing greater control and efficacy to your cleaning/disinfecting programs.

A Smarter Dispenser...

- **Spring-loaded lid closes automatically**, keeping wipers wet, minimizing waste and preventing chemical vapors and splashes.
- **Enclosed, single-use system** reduces risk of cross contamination — no cloth re-wetting.
- **Compact and portable** – ready-to-use prepared wipers make on-the-go disinfecting fast, easy and effective.
- **Controlled chemical usage** prevents over use or under use, ensuring consistent product application.
- **Dispenses cost-effective, single-use disposable wipers** – no laundering or extra handling required.

A Better Wiper...

- Hybrid fabric incorporates both meltblown and spunbound technologies – works effectively with hydrogen peroxide/peroxyacetic acid disinfectant cleaning solutions, such as SSS-Sanotracin RTU™ and diluted Concentrate, as well as quaternary ammonium disinfectants.
- Lint-free, non-textured fabric provides consistent solution release, ensuring full product efficacy with every use.
- 2.5 times stronger than ordinary disinfectant wipes for superior soil removal – available in convenient 6" x 8" and 10" x 12" sizes.
- Advanced fabric absorbs and releases solutions more efficiently, resulting in chemical savings and a significantly lower cost-per-wipe.

Environmental Surface Wiping System

The cost-effective Sanotex system optimizes control and efficiency to produce better, more consistent results for your disinfecting program. The Sanotex advantage: An enclosed dispenser that preserves

wiper and chemical efficacy, plus advanced wiper fabric that works effectively with multiple chemical formulations. The result: improved performance at *significantly lower cost per wiper*.

How to use the Sanotex Wiping System:



A

Insert a dry roll of Sanotex wipers into the dispenser.



C

From the center of the roll, pull a wiper up and carefully thread through opening in dispenser lid approximately one inch. Replace lid, screwing on tightly.



B

Carefully pour chemical solution over center of wiper roll in dispenser, using approximately 24 oz. (0.7 liters) per roll.* Allow five minutes before use to assure proper saturation of wipers.



D

To dispense, open the hinged lid and pull the wiper through the opening at an angle. The spring-loaded lid will re-close automatically.

*Product shelf life is 15 days when saturated with quaternary ammonium disinfectant or hydrogen peroxide/peracetic acid disinfectant.

ITEM #	DESCRIPTION	PACK	COUNT	SIZE	COLOR
18005	SSS-Sanotex Environmental Surface Wipes - includes one dispenser bucket	6/cs	150	6" x 8"	White
18006	SSS-Sanotex Environmental Surface Wipes - includes one dispenser bucket	6/cs	60	10" x 12"	White
18007	SSS-Sanotex Environmental Surface Wipes Dispenser - fits both size wipers	6/cs	—	—	—
18001	SSS-Sanotracin Sporidical Disinfectant Cleaner RTU	6/cs [†]	—	1-qt.	—
18002	SSS-Sanotracin Sporidical Disinfectant Cleaner RTU	4/cs	—	1-gal.	—
18011**	SSS-Sanotracin Sporidical Disinfectant Cleaner Concentrate for Navigator DCS	2/cs	—	2-liter	—
18012**	SSS-Sanotracin Sporidical Disinfectant Cleaner Concentrate	4/cs	—	1-gal.	—



[†] Includes 3 spray applicators and 3 flip-top applicators

**Available June 2013